

BENCHTOP INSTRUMENT



S.M.CREATIVE
ELECTRONICS LIMITED

**Triple Output Digital
Power Supply
Model No.: SMC-3303X**

Operation Manual

No.35, Hartron Complex, Sector-18, Electronic City, Type-A, Udyog Vihar, Phase-IV, Gurugram 122015 Haryana, India

Tel: +91-124-4909 850; Fax: +91-11 66173638

Email: ptgsales@smcel.com; Web: www.smcel.com

| | |
|--|--------|
| SAFETY INSTRUCTION | I |
| 1. OVERVIEW | - 1 - |
| 1.1 Operation and Storage Environment | - 1 - |
| 1.2 Introduction | - 1 - |
| 1.5 Front Panel Overview | - 2 - |
| 1.6 Rear Panel Overview | - 5 - |
| 1.7 CV/CC Crossover Characteristics | - 6 - |
| 2. SETUP | - 7 - |
| 2.1 Power Up | - 7 - |
| 2.2 Load Cable Connection | - 7 - |
| 2.3 Output ON/OFF | - 8 - |
| 2.4 Beep ON/OFF | - 8 - |
| 2.5 Front Panel Lock | - 8 - |
| 3. OPERATION | - 9 - |
| 3.1 CH1/CH2 Independent Mode | - 9 - |
| 3.2 CH3 Independent Mode | - 9 - |
| 3.3 CH1/CH2 Tracking Series Mode | - 10 - |
| 3.4 CH1/CH2 Tracking Parallel Mode | - 13 - |
| 4. SAVE/RECALL SETUP | - 15 - |
| 4.1 Save Setup | - 15 - |
| 4.2 Recall Setup | - 15 - |
| 5. REMOTE CONTROL | - 16 - |
| 5.1 Remote Control Setup | - 16 - |
| 5.2 Remote Connection Step | - 16 - |
| 5.3 Command Syntax | - 17 - |
| 5.4 Error Messages | - 17 - |
| 5.5 Command List | - 17 - |
| 5.6 Command Details | - 18 - |
| 6. MAINTENANCE | - 21 - |
| 6.1 Inspection | - 21 - |
| 6.2 Fuse Replacement | - 21 - |
| 6.3 Cleaning | - 21 - |

SAFETY INSTRUCTION

This chapter contains important safety instructions that you must follow when operating the instrument and when keeping it in storage. Read the following before any operation to insure your safety and to keep the best condition for the instrument.

Safety Symbols

The following safety symbols may appear in this manual or on the instrument:



WARNING Identifies conditions or practices that could result in injury or loss of life.



CAUTION Identifies conditions or practices that could result in damage to the instrument or to other properties.



DANGER High voltage



ATTENTION Refer to the manual



Protective conductor terminal



Earth (ground) terminal

Safety Guidelines



CAUTION

- Before plugging into local AC mains, check and make sure that the output voltage is compatible to the load. (It is suggested to disconnect a load before plugging into local AC mains.
- Do not use this instrument near water.
- Do not operate or touch this instrument with wet hands.
- Do not open the casing of the instrument when it is connected to AC mains.
- The max.output voltage of the instrument may be over 60VDC, avoid touch the metal contact part of the output terminals.
- Do not use the instrument in an atmosphere which contains sulfuric acid mist or other substances which cause corrosion to metal.
- Do not use the instrument in a dusty place or a highly humid place as such will cause instrument reliability degradation and instrument failures.
- Install the instrument in a place where is free from vibration.
- Install the instrument in a place where the ambient temperature is in range of -10~70°C. Note that the instrument operation may become unstable if it is operated in an ambient temperature exceeding the range of 0~40°C

Power supply

AC Input voltage: 110V/220V \pm 10%, 50/60Hz



WARNING

Connect the protective grounding conductor of the AC power cord to an earth ground to avoid electrical shock.

Fuse



WARNING

- Fuse type: 110V: T6.3A /250V, 220V: T3.15A/250V.
- Make sure the correct type of fuse is installed before power up.
- Replace the AC fuse with the same type and rating as the original fuse.
- Disconnect the power cord before fuse replacement.
- Make sure the cause of fuse blowout is fixed before fuse replacement.

1. OVERVIEW

This chapter describes the instrument in a nutshell, including its main features and front /rear panel introduction. After going through the overview, follow the SETUP chapter to properly power up and set operation environment.

1.1 Operation and Storage Environment

Operation Environment

Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (note below)

Relative Humidity: < 80%

Altitude: < 2000m

Temperature: 0° to 40°

Storage Environment

Location: Indoor

Relative Humidity: < 70%

Temperature: -10° to 70°

1.2 Introduction

This series of regulated programmable DC power supply are light weight, adjustable, multifunctional work stations. They have three independent outputs: two with adjustable voltage level and one with fixed level selectable from 2.5V, 3.3V and 5V. The power supply can be used for logic circuits where various output voltage or current are needed, and for tracking mode definition systems where positive and negative voltages with good accuracy are required.

Independent /Tracking Series /Tracking Parallel

The three output modes of the power supply - independent, tracking series, and tracking parallel - can be selected by pressing the TRACKING key on the front panel. In the independent mode, the output voltage and current of each channel are controlled separately. The isolation degree, from output terminal to chassis or from output terminal to output terminal, is 300V. In the tracking modes, both the CH1 and CH2 outputs are automatically connected in series or parallel; no need to connect output leads. In the series mode, the output voltage is doubled; in the parallel mode, the output current is doubled.

Constant Voltage/Constant Current

Except for CH3, each output channel is completely transistorized and well-regulated, and works in constant voltage (CV) or constant current (CC) mode. Even at the maximum output current, a fully rated, continuously adjustable output voltage is provided. For a big load, the power supply can be used as a CV source; while for a small load, a CC source. When in the CV mode (independent or tracking mode), output current (overload or short circuit) can be controlled via the front panel. When in the CC mode (independent mode only), the maximum (ceiling) output voltage can be controlled via the front panel. The power supply will automatically cross over from CV to CC operation when the output current reaches the target value. The power supply will automatically cross over from CC to CV when the output voltage reaches the target value. For more details about CV/CC mode operation, see page8.

Automatic Tracking Mode

The front panel display (CH1, CH2) shows the output voltage or current. When operating in the tracking mode, the power supply will automatically connect to the auto- tracking mode.

Main Features

| | | |
|-------------|---|---------------------------------------|
| Performance | ➤ Low ripple & noise, intelligent cooling fan | |
| | ➤ Compact design, light weight | |
| Operation | ➤ Constant voltage/constant current operation | |
| | ➤ Tracking series/tracking parallel operation | |
| | ➤ Output ON/OFF control | |
| | ➤ 3 outputs:30V/3A×2, 2.5V/3.3V/5V/3A×1 | |
| | ➤ Digital panel control | |
| | ➤ Panel lock function | |
| | ➤ 4 programming presets for voltage and current save/recall | |
| | ➤ Coarse and fine control for voltage and current | |
| Protection | ➤ Over load, over temperature protections | |
| | ➤ Reverse polarity protection | |
| | Interface | ➤ USB interface for remote PC control |

1.5 Front Panel Overview






Fig.1.5-1 Front panel

Display

Voltmeter Displays CH1 or CH2 output voltage



Ammeter Display CH1 or CH2 output current



Control Panel

Memory keys



Saves or recalls panel settings. Max.4 sets for programming preset. Refer to page 17 for details.

CH1/CH2
beep keys



Selects the output channel for level adjustment. Refer to page 11 for level setting details
Pressing and holding CH2 key enables beep sound. Refer to page 10 for details.

Parallel/Series
keys



Activates Tracking Parallel operation or Tracking Series operation. Refer to page 12 for details.

Lock key



Locks or unlocks the front panel settings. Refer to page 10 for details.

Output key



Turns the output on or off.

Voltage
knobs



VOLTAGE



Adjusts the output voltage level for CH1 or CH2. Pressing the knob switches for coarse and fine level setting. When in fine adjustment, the FINE indicator lights on.

Current knobs




CURRENT



Adjusts the output current level for CH1 or CH2. Pressing the knob switches coarse and fine level setting. When in fine adjustment, the FINE indicator lights on.

Terminals

| | | |
|-----------------------------|---|--|
| Power switch |  | Turns on <input type="checkbox"/> or off <input type="checkbox"/> the main power. Refer to page 9 for power up sequence. |
| GND terminal |  | Accepts a grounding wire. |
| CH1 output |  | Outputs CH1 voltage and current. |
| CH1 CV/CC indicator |  | Indicates CH1 constant voltage or constant current operation mode. |
| CH2 output |  | Outputs CH2 voltage and current. |
| CH2 CV/CC/ PAR indicator |  | Indicates CH2 constant voltage, constant current or tracking parallel operation mode. |
| CH3 output |  | Outputs CH3 voltage and current. |
| CH3 overload Indicator |  | Indicates when CH3 output current is overloaded. |
| CH3 voltage Selector |  | Selects CH3 output voltage from 2.5V, 3.3V, 5V. |

1.6 Rear Panel Overview







Fig.1.6-1 Rear panel of models with USB interface



Accepts a USB slave connector for command-based remote control (page 18).
For models with USB interface.



The power cord socket accepts the AC mains. Refer to page 9 for power up details.
The fuse holder contains the AC main fuse. Refer to page 23 for details of fuse replacement.



Selects AC line voltage from 110V/220V.


1.7 CV/CC Crossover Characteristics

Background The instrument automatically switches between constant voltage mode (CV) and constant current mode (CC), according to load condition.

CV mode When the current level is smaller than the output setting, the instrument operates in Constant Voltage mode. The indicator on the front panel turns green (C.V.) The Voltage level is kept at the setting and the Current level fluctuates according to the load condition until it reaches the output current setting.

CC mode When the current level reaches the output setting, the instrument starts operating in Constant Current mode. The indicator on the front panel turns red (C.C.) The Current level is kept at the setting but the Voltage level becomes lower than the setting, in order to suppress the output power level from overload. When the current level becomes lower than the setting, the instrument goes back to the Constant Voltage mode.

Diagram




2. SETUP

This chapter describes how to properly power up and configure the power supply series before operation.

2.1 Power Up


Select AC line voltage Before powering up the power supply, select the AC input voltage from the rear panel. voltage



Connect AC power cord Connect the AC power cord to the rear panel socket. power cord



Power on Press the power switch to turn on the power. The display shows the initialization screen, followed by the last recalled settings.





Power off Press the power switch again to turn off the power.




2.2 Load Cable Connection

Standard accessory 1. Turn the terminal counterclockwise and loosen the screw.
2. Insert the cable terminal.
3. Turn the terminal clockwise and tighten the screw.



Banana plug Insert the plug into the socket.




Wire type When using load cables other than the attached, make sure they have enough current capacity for minimizing cable loss and load line impedance. Voltage drop across a wire should not exceed 0.5V. The following list is the wire current rating at 450A/cm².

| Wire size (AWG) | Max. current (A) |
|-----------------|------------------|
| 20 | 2.5 |
| 18 | 4 |
| 16 | 6 |
| 14 | 10 |
| 12 | 16 |

2.3 Output ON/OFF

Panel operation

Pressing the Output key turns on all CH 1/2/3 outputs.



The key LED also turns on. Pressing the Output key again turns off the output and the key LED.

Automatic
output off

Any of the following actions during output on automatically turns it off. They might involve sudden and harmful change in the output level.

- Change the operation mode between independent / tracking series / tracking parallel
 - Recalling other setups from the memory
 - Storing the setup into the memory
-

2.4 Beep ON/OFF

Panel operation

By default, the beeper sound is enabled. To turn off the beep, press the beep key for 2 seconds.



A beep sound comes out and the beeper setting will be turned off. To enable the beeper, press the beep key again for 2 seconds.

List of beeper

The following operations go with a beep sound when the beeper setting is on.

Power on

Output on/off

INDEP – SER – PAR mode switching

Panel lock/unlock

Setup save/recall

CH1/CH2 output level knob

Voltage/current knob, fine/coarse knob

Voltage/current level reaching minimum (zero) level

2.5 Front Panel Lock

Panel operation

Press the LOCK key to lock the front panel key operation. The key LED turns on. To unlock, press the LOCK key for 2 seconds. The key LED also turns off.



Note


The OUTPUT key is not affected by the lock operation.



3. OPERATION


3.1 CH1/CH2 Independent Mode

Background/ Connection CH1 and CH2 outputs work independent of each other and are separately controlled.




Output rating 0~30V/0~3A for each channel ($I \leq 3A$)
0~30V/0~5A for each channel ($I > 3A$)

- Panel operation
1. Make sure the PARA INDEP and SERIES INDEP keys are turned off (the key LEDs are off) 
 2. Connect the load to the front panel terminals, CH1 +/-, CH2 +/-- 



3. Set the CH1 output voltage and current. Press the CH1 switch (LED turns on) and use the Voltage and Current knob. By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.




(Fine control)

Coarse: 0.1V or 0.1A @ rotation click.
Fine: the smallest digit @ rotation click.




4. Repeat the above settings for CH2 channel.
5. To turn on the output, press the output key. The key LED turns on and the CH1 /CH2 indicator shows the output mode, CV or CC.



3.2 CH3 Independent Mode


Background/ Connection The CH3 rating is 2.5V/3.3V/5V, maximum 3A. It works independently from CH1 and CH2, regardless of their modes.




Output rating Fixed 2.5V/3.3V/5V, 3A

No tracking CH3 does not have tracking series/parallel mode. Also, CH3 output is not affected by CH1 and 2
Series/Parallel modes.
mode

Panel operation 1. Connect the load to the front panel CH3 +/- terminal.



2. Select the output voltage from 2.5V, 3.3V and 5V, using the CH3 voltage selector switch.



3. To turn on the output, press the output key. The key LED turns on.



CC to CV When the output Current level exceeds 3A, the overload indicator turns red and CH3 operation mode switches from Constant Voltage to Constant Current.



Note: “overload” in this case does not mean an abnormal operation.


3.3 CH1/CH2 Tracking Series Mode

Background Tracking series operation doubles the Voltage capacity of the power supply series by internally connecting CH1 (Master) and CH2 (Slave) in series and combining the output to a single channel. CH1 (Master) controls the combined Voltage output level.

The following describes two types of configurations depending on the common ground usage.

Tracking series without common terminal


Connection




Output rating 0~60V/0~3A ($I \leq 3A$)
0~60V/0~5A ($I > 3A$)

Panel operation

1. Press the SER/INDEP key to activate the tracking series mode. The key LED turns on.
2. Connect the load to the front panel terminals, CH1+ & CH2-. (Single supply).



3. Press the CH2 switch (LED turns on) and use the Current knob to set the CH2 output current to the maximum level. By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.




(Fine control)

Coarse: 0.1V or 0.1A @ rotation click.

Fine: the smallest digit @ rotation click.



4. Press the CH1 switch (LED turns on) and use the Voltage and Current knob to set the output voltage and current level.



5. To turn on the output, press the output key. The key LED turns on.




6. Refer to the CH1 (Master) meter and indicator for the output setting level and CV/CC status.



| | |
|---------------|---|
| Voltage level | Double the reading on the CH1 Voltage meter. In the above case, the actual output is $20.0 \times 2 = 40.0V$. |
| Current level | CH1 meter reading shows the output Current. In the above case, 2.000A. (CH2 Current control must be in the Maximum position= $3.0A(I \leq 3A)$ or $5.0A(I > 3A)$). |


Tracking series with common terminal

Connection



| | | |
|---------------|--|-------------------------------------|
| Output rating | 0~30V/0~3A for CH1~COM ($I \leq 3A$) | 0~30V/0~5A for CH1~COM ($I > 3A$) |
| | 0~30V/0~3A for CH2~COM ($I \leq 3A$) | 0~30V/0~5A for CH2~COM ($I > 3A$) |

- Panel operation
1. Press the SER/INDEP key to activate the tracking series mode. The key LED turns on.
 2. Connect the load to the front panel terminals, CH1+/- & CH2-. Use the CH1 (-) terminal as the common line connection.



3. Press the CH1 switch (LED turns on) and use the Voltage knob to set the master & slave output voltage (the same level for both channels). By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.




Coarse: 0.1V or 0.1A @ rotation click.
 Fine: the smallest digit @ rotation click.

4. Use the current knob to set the master output current.



5. To turn on the output, press the output key. The key LED turns on.




6. For the master (CH1) output level and CV/CC status, refer to the CH1 meter and indicator.



Master (CH1) voltage level: CH1 meter reading shows the output voltage. In the above case, 20.0V.

Master (CH1) current level: CH1 meter reading shows the output current. In the above case, 2.000A.

7. Press the CH2 switch (LED turns on) and use the Current knob to set the slave output current.



8. For the slave (CH2) output level and CV/CC status, refer to the CH1/2 meter and CH2 indicator.




Slave (CH1) voltage level: CH1 meter reading shows the output voltage. In the above case, 20.0V.

Slave (CH1) current level: CH1 meter reading shows the output current. In the above case, 2.000A.

3.4 CH1/CH2 Tracking Parallel Mode

Background/
connection

Tracking parallel operation doubles the current capacity of the power supply series by internally connecting CH1 and CH2 in parallel and combining the output to a single channel. CH1 controls the combined output.




Output rating 0~30V/0~6A ($I \leq 3A$)
 0~30V/0~10A ($I > 3A$)

- Panel operation 1. Press the PAR/INDEP key to activate the tracking parallel mode.



The key LED turns on.

2. Connect the load to the CH1 +/- terminals.




3. To turn on the output, press the output key. The key LED turns on.



4. The CH2 indicator turns red, indicating tracking parallel (PAR) mode.



5. Press the CH1 switch (LED turns on) and use the Voltage and Current knob to set the output voltage and current. The CH2 output control is disabled. By default, the Voltage and Current knob work in the coarse mode. To activate the fine mode, press the knob and turn on the FINE LED.



6. For the output level and CV/CC status, refer to the CH1 meter and indicator.



Voltage level: The CH1 meter reading shows the output voltage. In the above case, 20.0V.

Current level: Double the amount of CH1 current meter reading. In the above case,


$$2.0\text{A} \times 2 = 4.0\text{A}.$$

4. SAVE/RECALL SETUP

4.1 Save Setup

| | |
|------------|--|
| Background | The front panel settings can be stored into one of the four internal memories. |
|------------|--|

| | |
|----------------------|---|
| Programming contents | <p>The following list shows the programming setting contents:</p> <ul style="list-style-type: none">➤ Independent / tracking series / tracking parallel mode➤ CH1/CH2 knob selection➤ Fine/coarse knob editing mode➤ Beep on/off➤ Output voltage/current level <p>The following settings are always saved as “off”:</p> <ul style="list-style-type: none">➤ Output on/off➤ Front panel lock on/off |
|----------------------|---|


| | |
|-----------------|---|
| Panel operation | <p>Press one of the 1~4 Memory keys for 2 seconds, for example memory 1. The panel settings will be saved in memory 1 by long push to this key and the key LED turns on. When the panel settings are modified, the LED turns off.</p>  |
|-----------------|---|

Note When the setting is stored, the output automatically turns off.

4.2 Recall Setup

| | |
|------------|--|
| Background | The front panel settings can be recalled from one of the four internal memories. |
|------------|--|


| | |
|----------------------|--|
| Programming contents | <p>The following list shows the programming setting contents:</p> <ul style="list-style-type: none">➤ Independent / tracking series / tracking parallel mode➤ CH1/CH2 knob selection➤ Fine/coarse knob editing mode➤ Beep on/off➤ Output voltage/current level <p>The following settings are always recalled as “off”:</p> <ul style="list-style-type: none">➤ Output on/off➤ Front panel lock on/off |
|----------------------|--|

| | |
|-----------------|---|
| Panel operation | <p>Press one of the 1~4 Memory keys, for example memory 1. The panel settings saved in memory 1 will be recalled by pressing this key. The key LED turns on. When the panel settings are modified, the LED turns off.</p>  |
|-----------------|---|

Note When a setting is recalled, the output automatically turns off.

5. REMOTE CONTROL

5.1 Remote Control Setup


| | |
|---------------------|---|
| Background | The power supply is capable of being remotely controlled via the USB connection. |
| Interface |  USB slave port, rear panel |
| COM setting | Set up the COM port inside the PC according to the following list: Baud rate: 9600 Parity bit: None Data bit: 8 Stop bit: 1 Data flow control: None |
| Functionality check | Run this query command via the terminal application such as MTTTY (Multi-threaded TTY). *IDN? This should return the identification information: series number, firmware version. |

5.2 Remote Connection Step

- Enter the remote control mode
1. Connect the USB cable to the slave port.
 2. The connection will be automatically established, and the front panel shows “USB...YES” message.



3. The power supply also automatically enters the lock state (the Lock key will be activated).



- Exit the remote control mode
1. Disconnect the USB cable from the rear.
 2. The display shows “USB...NO” message.



3. Unlock the power supply by pressing the Lock key until it turns off backlight.



4. The power supply goes back to local operation mode.

5.3 Command Syntax

| | | | | |
|----------------|----------------------------------|-----------------|-----------------|--|
| Command format | | | | 1: command header 2: output channel 3: separator 4: parameter |
| Parameter | Type | Description | Example | |
| | <Boolean> | Boolean logic | 0 (off), 1 (on) | |
| | <NR1> | Integers | 0, 1, 2, 3 | |
| | <NR2> | Decimal numbers | 0.1, 3.14, 8.5 | |
| Output channel | 1 (CH1) or 2 (CH2) | | | |
| Note | Commands must be capital letters | | | |

5.4 Error Messages

The following error messages might appear when the power supply cannot accept the command.

| Message contents | Descriptions |
|-----------------------------|---|
| a Program mnemonic too long | The command length must be 15 characters or less. |
| b Invalid character | Invalid characters, such as symbols, are entered. Example: VOUT# |
| c Missing parameter | The parameter is missing from the command. Example: VSET: (should have a number) |
| d Data out of range | The entered value exceeds the specification. Example: VSET:33 (should be $\leq 32V$) |
| e Command not allowed | The entered command is not allowed in the circumstance. Example: trying to set CH2 output while in the tracking mode. |
| f Undefined header | The entered command does not exist, or the syntax is wrong. |

5.5 Command List

Detailed descriptions of each command starts from the next page.

The “HELP” command shows all the following commands and their meanings, except for the HELP command itself.

| Command | Meanings |
|---------------|------------------------------------|
| ISET<X>:<NR2> | Sets the output current |
| ISET<X>? | Returns the output current setting |
| VSET<X>:<NR2> | Sets the output voltage |
| VSET? | Returns the output voltage setting |
| IOUT<X>? | Returns the actual output current |
| VOUT<X>? | Returns the actual output voltage |
| TRACK<NR1> | Selects the operation mode |
| BEEP<BOOLEAN> | Turn on or off the beep |
| OUT<BOOLEAN> | Turn on or off the output |
| STATUS? | Returns the MODEL status |

| | |
|-----------|---------------------------------------|
| *IDN? | Returns the MODEL identification |
| RCL<NR1> | Recalls a panel setting |
| SAVE<NR1> | Saves the panel setting |
| HELP? | Shows the command list |
| ERR? | Returns the instrument error messages |

5.6 Command Details

| Command | ISET<X>:<NR2> |
|-----------------|--|
| Description | Sets the output current. |
| Panel operation | Refer to page 11 |
| Response time | Min.70ms |
| Example | ISET1:2.234 Sets the CH1 output current to 2.234A. (for 1mV 1mA models) ISET1:2.23 Sets the CH1 output current to 2.23A. (for 10mV 10mA /100mV 10mA models) |

| Command | ISET<X>? |
|---------------|---|
| Description | Returns the output current setting |
| Response time | Min.70ms |
| Example | ISET1? Returns CH1 output current setting. |

| Command | VSET<X>:<NR2> |
|-----------------|--|
| Description | Sets the output voltage. |
| Panel operation | Refer to page 11 |
| Response time | Min.70ms |
| Example | VSET1:20.345 Sets the CH1 voltage to 20.345V.(for 1mV 1mA models) |

| Command | VSET<X>? |
|---------------|--|
| Description | Returns the output voltage setting. |
| Response time | Min.70ms |
| Example | VSET1? Returns the CH1 voltage setting. |

| Command | IOUT<X>? |
|---------------|---|
| Description | Returns the actual output current. |
| Response time | Min.70ms |
| Example | IOUT1? Returns the CH1 output current. |

| Command | VOUT<X>? |
|---------------|---|
| Description | Returns the actual output voltage. |
| Response time | Min.70ms |
| Example | VOUT1? Returns the CH1 output voltage. |

| Command | TRACK<NR1> |
|-----------------|---|
| Description | Selects the operation mode: INDEP, tracking SER, tracking PAR |
| Panel operation | Refer to page 12 |
| NR1 | 0: Independent 1: Tracking series 2: Tracking parallel |
| Response time | Min.70ms |

| Command | BEEP<Boolean> |
|-----------------|-------------------------------|
| Description | Turns on or off the beeper. |
| Panel operation | Refer to page 10 |
| Response time | Min.70ms |
| Example | BEEP1 Turns on the beeper. |

| Command | OUT<Boolean> |
|-------------|-----------------------------|
| Description | Turns on or off the output. |

| | |
|---------|---|
| Example | TRACK0 Selects the independent mode. |
|---------|---|

| | |
|-----------------|------------------------------|
| Panel operation | Refer to page 10 |
| Response time | Min.70ms |
| Example | OUT1 Turns on the output. |

| | |
|----------------|---|
| Command | STATUS? |
| Description | Returns the MODEL status. |
| Response time | Min.400ms |
| Contents | 8 bits in the following format. (Refer to table on the right.) |

| Bit | Item | Description |
|------|----------|--|
| 0 | CH1 | 0=CC mode, 1=CV mode |
| 1 | CH2 | 0=CC mode, 1=CV mode |
| 2, 3 | Tracking | 01=Independent, 11=Tracking series, 10=Tracking parallel |
| 4 | Beep | 0=Off, 1=On |
| 5 | N/A | N/A |
| 6 | Output | 0=Off, 1=On |
| 7 | N/A | N/A |

| | |
|-----------------|---|
| Command | SAV<NR1> |
| Description | Saves the panel setting. |
| Panel operation | Refer to page 17 |
| NR1 | 1~4: Memory 1 to 4 |
| Reponses time | Min.70ms |
| Example | SAV1 Stores the panel setting into memory 1. |

| | |
|-----------------|---|
| Command | RCL<NR1> |
| Description | Recalls a panel setting. |
| Panel operation | Refer to page 17 |
| NR1 | 1~4: Memory 1 to 4 |
| Reponses time | Min.70ms |
| Example | RCL1 Recalls the panel setting stored in memory 1. |

| | |
|----------------|----------------------------------|
| Command | *IDN? |
| Description | Returns the MODEL identification |
| Reponses time | Min.300ms |
| Contents | Series number, firmware version |

| | |
|----------------|-------------------------------|
| Command | HELP? |
| Description | Shows the command list. |
| Reponses time | Min.1000ms |
| Contents | Refer to the following table. |

| | |
|----------------|--|
| Command | ERR? |
| Description | Checks the error status of the instrument and returns the last error message |
| Reponses time | Min.70ms |
| Contents | See page 19 for list of error messages. |

Contents for Command HELP

| | |
|---|---|
| ISET<x>:<NR2> | Sets the value of current. |
| VSET<x>:<NR2> | Sets the value of voltage. X: 1=CH1, 2=CH2. |
| ISET<x>? | Return the value of current. |
| VSET<x>? | Return the value of voltage. |
| IOUT<x>? | Returns actual output current. |
| VOUT<x>? | Returns actual output voltage. |
| TRACK<NR1> | Sets the output of the power supply working on independent or tracking mode. NR1: 0=INDE, 1=SER, 2=PARA. |
| BEEP<Boolean> | Sets the BEEP state on or off. |
| OUT<Boolean> | Sets the output state on or off |
| STATUS? | Returns the power supply state. |
| bit0:(CH1)0=CC,1=CV | |
| bit1:(CH2)0=CC,1=CV | |
| bit23:(TRACK)01=INDEP, 11=SER,10=PAR | |
| bit4:(BEEP)0=OFF,1=ON | |
| bit6:(OUT)0=OFF,1=ON | |
| *IDN? | Returns instrument identification. |
| RCL<NR0> | Recall the setting data from the memory which previous saved. |
| SAV<NR0> | Saves the setting data to memory. |
| NR0: 1=Memory1, 2=Memory2, 3=Memory3, 4=Memory4; | |


6. MAINTENANCE

6.1 Inspection


- Inspect the instrument at regular intervals so that it maintains its initial performance for a long time.
- Check the input power cord for damage of the vinyl cover and overheating of the plug and cord stopper. Check the terminal screws and binding posts for loosening.
- Remove dust from the inside of the casing and ventilation holes of the cover by using a compressed air of the exhaust air of a vacuum cleaner.

6.2 Fuse Replacement

- Steps 1. Take off the power cord and remove the fuse socket using a minus driver.



2. Replace the fuse in the holder.



Fuse rating 110V: T6.3A/250V
220V: T3.15A/250V

6.3 Cleaning

- Before cleaning, disconnect the AC mains.
- To clean the power supply, use a soft cloth dampened in a solution of mild detergent and water. Do not spray cleaner directly onto the instrument, since it may leak into the cabinet and cause damage.
- Do not use chemicals containing benzene, benzene, toluene, xylene, acetone, or similar solvents.
- Do not use abrasive cleaners on any portion of the instrument.